


DG400

394,000 BTU



DG400

394,000 BTU



Item	Part #	Description
1	BIE G06139-9005	Outlet cone
2	BIE M10203/1/B	Screw
3	BIE G03114	Front disc
4	BIE G03147	Combustion chamber
5	BIE E50745	Safety thermostat
6	BIE M20413	Hose bracket
7	BIE G03150-9010	Lower body
8	BIE G03152-9010	Inspection panel
9	BIE G03154-9010	Lower body
10	BIE C30372 Cable	protection \$
11	BIE G03126	Rear disc
12	BIE GA.0100206	Ionisation electrode
13	BIE I40332	Silicone pipe
14	BIE I39106	Flex gas pipe
15	BIE I20326	Fitting
16	BIE G06239-9010	Air conveyor
17	BIE C30374	Pipe cap
18	BIE E10704-110	Motor
19	BIE E11249	Capacitor
20	BIE T10261	Fan
21	BIE P30129	Inlet grill
22	BIE G06330-9005	Valve support plate
23	BIE I39102	Seal
24	BIE I31205-1	Fitting
25	BIE I20326	Fitting
26	BIE I31204	Fitting
27	BIE T30330-2	Gas selector valve
31	BIE T30333	Gas manual valve
32	BIE E20943	Cable fastener
33	BIE E20932	Cable fastener nut
34	BIE T30111	Gas valve unit
35	BIE G06332-9005	Gas valve support bracket
36	BIE M20907	Stirrup
37	BIE G03157-9010	Pressure switch support bracket
38	BIE E50443	Pressure switch
39	BIE I30414	Filter
40	BIE E50441	Pressure switch
41	BIE I40336	Rilsan pipe
42	BIE I40335	Silicone pipe
43	BIE I20669	Hose connection
44	BIE E20952	Cable fastener
45	BIE E20955	Cable fastener nut
46	BIE C30376	Cable protection
47	BIE E50750	Safety thermostat plastic profile
48	BIE G03159-9010	Base
49	BIE P50127	Control box cover
50	BIE G00286-5P	El. control box
51	BIE G03176	El. control box panel
52	BIE E20508	Fuse holder
53	BIE E10313	Fuse
54	BIE E11153	Relay
55	BIE E20319	Ground terminal board
56	BIE E20305	Terminal board

Item	Part #	Description
57	BIE E10931	H.T. Transformer
58	BIE E40229	Flame control box
59	BIE E11125	Relay
60	BIE G06073	Support plate
61	BIE E20418	Stop button protection
62	BIE E10110-1-P	Switch
63	BIE E20639	Thermostat plug (5 pin)
64	BIE E20966	Plug with jumper (5 pin)
65	BIE E30443	Power cord
66	BIE E11030	Lamp
70	BIE I20325	Fitting
71	BIE I31130	Brass hose connection
72	BIE M10323/1	Screw
73	BIE GA.0010208	Burner disc
74	BIE GA.0100204	Diffuser ring
75	BIE E20679	Terminal board
76	BIE G03129	Burner support plate
77	BIE E10215	Ignition electrode
78	BIE G02078	H.T. Cable connection
79	BIE G03168-9005	Lifting bracket
80	BIE G03169-9005	Lifting bracket
81	BIE G03170-9005	Frame
82	BIE G03171-9005	Wheel axle
83	BIE M20111	Washer
84	BIE C10556	Wheel
85	BIE M20505	Latched pin
86	BIE G03172-9005	Support
87	BIE G03173-9005	Frame
88	BIE G03174-9005	Frame
89	BIE G03175-9005	Handle
90	BIE C10203	Handle
91	BIE E11021	Lamp
92	BIE I31131	Brass hose connection

NOTE:

For units prior to SN 43403001

50	BIE G00286	El. comp. drawer
63	BIE E20640	Thermostat plug 4P (4 pin)
64	BIE E20675	Plate plug 3P+T(4 pin)

NOTE:

For units SN 43400232 and beyond

18	BIE E10772	Motor
19	BIE E10772-1	Capacitor
65	BIE E30443-1	Cord only
93	BIE E20965	Cable nut
94	BIE E20964	Cable fastener

Not shown

Fuse for Flame Control Box - E10325