


# S1505B Heater Parts

## Serial #3237 through #4276




Item	Part #	Description	Item	Part #	Description
<b>A1</b>	SFP S1505-56	Heater Body (Includes A10 & A11)	<b>C12</b>	SFP 5509	Snap Bushing, 1/2"
<b>A2</b>	SFP 2446	Limit Switch, 180F	<b>C13</b>	SFP S1500-710	Adjusted Air Switch
<b>A3</b>	SFP S1500-104	Control Box Lid	<b>C14</b>	SFP 9294	Vinyl Tube, 3/16"
<b>A4</b>	SFP S1500-501	Control Box	<b>C15</b>	SFP S1500-109	Air Tube
<b>A5</b>	SFP 7723	Control Box Seal	<b>C16</b>	SFP 5515	Rubber Grommet
<b>A6</b>	SFP 2423	Fan Blade	<b>C17</b>	SFP 2554	Compression Fitting, 1/4" Tubex 1/8" MNPT
<b>A7</b>	SFP 9262	Motor, 1HP	<b>C18</b>	SFP S1500-502	Air Tube Bracket
<b>A8</b>	SFP SL11	B-53 Screen	<b>C19</b>	SFP 9293	Connector, 1/8" MNPT x .170" HB 90° Elbow
<b>A9</b>	SFP 6119	Wheel	<b>C20</b>	SFP S1500-716	Remote Thermostat Assembly W/Cable
<b>A10</b>	SFP SL11B-13	Nose Cone	<b>D1</b>	SFP S1500-105	Mounting Rail
<b>A11</b>	SFP SL11B-2	Heat Shield	<b>D2</b>	SFP 9443	Ground Terminal Block (WK 4SL/U) Green/Yellow
<b>B1</b>	SFP BV85-50	Burner	<b>D3</b>	SFP 9264	Power Relay, 120V
<b>B2</b>	SFP 2143	Spark Plug	<b>D4</b>	SFP 9264C	Relay Clip
<b>B3</b>	SFP SL11B-86	Flame Rod	<b>D5</b>	SFP 9280	End Plate (APC 1-2.5 D2/E), Green
<b>B4</b>	SFP 2539	Maunal Shut-Off Valve, 1-1/2"	<b>D6</b>	SFP 9275	Terminal Block (WKC 2.5 D2/2 SL35), Green
<b>B5</b>	SFP S1505-81	Gas Selector Valve, 1-1/2"	<b>D7</b>	SFP 9279	End Plate (APC 1-2.5 D2/E), Gray
<b>B6</b>	SFP 2537	Solenoid Valve, 1-1/4"	<b>D8</b>	SFP 9277	Terminal Block (WKC 2.5 E/35), Red
<b>B7</b>	SFP 4490	2-Stage Regulator, 1-1/4"	<b>D9</b>	SFP 9283	Gross Connector, 2 Pole
<b>B8</b>	SFP S1500-86B	Strainer Assembly, 1-1/4"	<b>D10</b>	SFP 9284	Gross Connector, 3 Pole
<b>B9</b>	ACC 11SV08	Regulator (optional)	<b>D11</b>	SFP 9285	Gross Connector, 5 Pole
<b>B10</b>	SFP 4509	Gas Pressure Switch	<b>D12</b>	SFP 9276	Terminal Block (WKC 2.5E), Gray
<b>C1</b>	SFP 9624	Flame Controller (Pin Connector)	<b>D13</b>	SFP 9274	Terminal Block (WKC 2.5 D2/2 SL35), Gray
	HWP HC1001D	Flame Controller (Tab 1/4")	<b>D14</b>	SFP 9278	Terminal Block (WKC 2.5 TKG/35), Gray
<b>C3</b>	SFP S1500-108	Wiring Duct	<b>D15</b>	SFP 9271	Fuse Holder
<b>C4</b>	SFP 9612	Start Button Assembly	<b>D16</b>	SFP 9270	Fuse, 2A
<b>C5</b>	SFP S1500-718	Start Contact Block Assembly	<b>D17</b>	SFP 9273	Terminal Block (WKC 2.5 D1/2/3.5), Gray
<b>C6</b>	SFP 9611	Stop Button Assembly	<b>D18</b>	SFP 9281	End Plate (APC 1-2.5 D1/TK), Gray
<b>C7</b>	SFP S1500-717	Stop Contact Block Assembly	<b>D19</b>	SFP 9282	End Plate (APC 1-2.5, Gray)
<b>C8</b>	SFP 8686	Thermostat Jumper Assembly\	<b>D20</b>	SFP 9272	Terminal Block (WKC 2.5/35), Gray
<b>C9</b>	SFP 8682	Thermostat Receptacle	<b>D21</b>	SFP 8659	Utility Box
<b>C10</b>	SFP 3868	Power Cord, 24"			
<b>C11</b>	SFP S1500-107	Wiring Duct, 7"			
			<b>Parts Not Shown</b>		
			SFP HC1008		Ignition/Flame Sensor Wire Kit

# S1505B

## Heater Parts

### Serial #4278 and Beyond



Item	Part #	Description
A1	SFP S1505-56	Heater Body (Includes A10 & A11)
A2	SFP 2446	Limit Switch, 180F
A3	SFP S1500-104	Control Box Lid
A4	SFP S1500-501	Control Box
A5	SFP 7723	Control Box Seal
A6	SFP 2423	Fan Blade
A7	SFP 9262	Motor, 1HP
A8	SFP SL11B-53 S	screen
A9	SFP 6119	Wheel
A10	SFP SL11B-13	Nose Cone
A11	SFP SL11B-2	Heat Shield
B1	SFP BV85-50	Burner
B2	SFP 2143	Spark Plug
B3	SFP SL11B-86	Flame Rod
B4	SFP 2539	Manual Shut-Off Valve, 1-1/2"
B5	SFP S1505-81	Gas Selector Valve, 1-1/2"
B6	SFP 2537	Solenoid Valve, 1-1/2"
B7	SFP 4490	2-Stage Regulator, 1-1/4"
B8	SFP S1500-86	Strainer Assembly, 1-1/4"
B9	ACC 11SV08*	Regulator (optional)
B10	SFP 4509	Gas Pressure Switch
C1	HWP HC1001D	Flame Controller (Tab 1/4")
C3	SFP S1500-108	Wiring Duct
C4	SFP 9612	Start Button Assembly
C5	SFP S1500-718	Start Contact Block Assembly
C6	SFP 9611	Stop Button Assembly
C7	SFP S1500-717	Stop Contact Block Assembly
C8	SFP S1500-713	Thermostat Jumper Assembly
C9	SFP 8682	Thermostat Receptacle
C10	SFP 3868	Power Cord, 24"
C11	SFP S1500-107	Wiring Duct, 7"
C12	SFP 5509	Snap Bushing, 1/2"

Item	Part #	Description
C13	SFP S1500-710	Adjusted Air Switch
C14	SFP 1707	Silicone Tube, 3/16"
C15	SFP S1500-109	Air Tube
C16	SFP 5515	Rubber Grommet
C17	SFP 2554	Compression Fitting, 1/4" Tubex 1/8" MNPT
C18	SFP S1500-502	Air Tube Bracket
C19	SFP 9293	Connector, 1/8" MNPT x .170" HB 90° Elbow
C20	SFP S1500-716	Remote Thermostat Assembly W/Cable
D1	SFP 9264C	Relay Holder Clip
D2	SFP 9264	Relay
D3	SFP S1500-105	DIN Mounting Rail
D4	SFP 4655	End Plate for 4668
D5	SFP 4668	Ground Terminal Block (gray)
D6	SFP 4654	End Plate for 4528
D7	SFP 4658	Terminal Block 2P+2P (gray)
D8	SFP 4657	End Plate for 4669
D9	SFP 4669	Terminal Block 4P (gray)
D10	SFP 4527	Fused Terminal Block (gray)
D11	SFP 4529	Terminal Block 3P (gray)
D12	SFP 4524	End Plate for 4529
D13	SFP 4530	Terminal Block 2P (gray)
D14	SFP 4525	End Plate for 4530
D15	SFP 4659	Utility Box
D16	SFP 9270	Fuse, 2A
	SFP 9271	Fuse Holder
D17	SFP 4526	End Plate for 4527
D18	SFP 4622	Jumper 5 Pole
D19	SFP 4523	Jumper 2 Pole
D20	SFP 4528	Terminal Block w/Light 2P+2P (red)
D21	SFP 4652	Jumper 3 Pole
D22	SFP 9443	Ground Terminal Block (green/yellow)
D23	WR4IEX-60	Ignition Wire
D24	WR7BAY-66	Flame Rod Wire